

OmniSTAR 8400HP



User Manual



Issue 2.2, Jan 2006

Notice to Customers

This manual has been produced to ensure the very best performance from your OmniSTAR receiver. The manual has been clearly set out with simple instructions to ensure trouble free usage of your OmniSTAR receiver.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the manual.

Should you require further assistance please contact your local dealer or the OmniSTAR B.V. office.

OmniSTAR Customer Support and 24-Hour Help Line

The Netherlands:

OmniSTAR B.V.
Dillenburgsingel 69
2263 HW Leidschendam
The Netherlands
Tel: +31 70 31 70 900
Fax: +31 70 31 70 919
Web: www.omnistar.nl
E-Mail: info@omnistar.nl

Australia:

OmniSTAR Pty Ltd
Tel: +61 8 9322 5295
Fax: +61 8 9322 4164
Web: www.omnistar.com.au
E-Mail: omnistar@omnistar.com.au

South Africa:

OmniSTAR Pty Ltd
Tel: +27 11 315 0420
Fax: + 27 11 312 1774
Web: www.omnistar.co.za
E-Mail: gsmith@omnistar.co.za

Singapore:

Fugro OmniSTAR Pte Ltd
Tel: +65 6542 5001
Fax: +65 6542 2208
E-Mail: sales@omnistar.com.sg

USA:

OmniSTAR Inc.
Tel: +1 713 785 5850
Fax: +1 713 785 5164
Web: www.omnistar.com
E-Mail: dgps2@omnistar.com

OmniSTAR 8400HP User Manual

One-Year Limited Hardware Warranty

OmniSTAR B.V and its operating companies world-wide (OmniSTAR), warrants this product to be free from defects in workmanship and material for a period of one year from the date of original sale by OmniSTAR or its authorised dealers, to the original purchaser or end user.

OmniSTAR reserves the right to repair and/or replace, at its option, any part or parts found to be defective, provided such defects, in their opinion, are due to faulty material or workmanship and are not caused by unauthorised or improper repair or abuse, or normal wear. Purchaser shall be responsible for shipping and insurance of the returned product for repair under this warranty. OmniSTAR will pay shipping and insurance for the product's return to purchaser provided that the product returned proves to be defective under this limited warranty.

This warranty applies only to normal usage of the product. It does not apply to units or electronic circuit boards defective due to improper installation or handling. Physical damage due to lightning or other electrical discharge and units subjected to fresh or salt-water contamination are not covered. OmniSTAR reserves the right not to warrant the product if, upon request, sufficient proof of recommended installation compliance as laid out in this manual is not provided. No other warranties are expressed or implied. No other warranties exist.

OmniSTAR assumes no responsibility for any consequential or incidental losses or damages of any nature with respect to the use of this product.

REVISION HISTORY

REVISION HISTORY		
Issue 0	December 2004	Draft
Issue 1	December 2004	Rx initial setup
Issue 2	June 2005	Firmware version p1
Issue 2.1	July 2005	Change baud rate, Ref. station list update
Issue 2.2	Aug 2005	Textual changes
Issue 2.21	Jan 2005	Minor change

Manual Reference: OmniSTAR 8400HP User Manual

OmniSTAR 8400HP User Manual

© Copyright OmniSTAR B.V. 2005. No part of this manual can be reproduced without the expressed permission of OmniSTAR B.V.

TABLE OF CONTENTS

INTRODUCTION	1
ABOUT THIS MANUAL	1
SYSTEM FEATURES	1
RECEIVER FEATURES	1
Housing	2
Interfaces	2
INSTALLATION AND SET UP	4
INSTALLATION CONSIDERATIONS	4
COUNTER ELECTROMAGNETIC FORCE (CEMF)	5
CABLE INSTALLATION	6
ADDITIONAL FEATURES AND INFORMATION	7
Sleep Mode	7
Zero Power Mode	7
Status Indicators	7
Clear NVRAM	9
ANTENNA LOCATION	10
POWER SUPPLY REQUIREMENTS	10
OPERATING CONSIDERATIONS	11
NUMBER OF VISIBLE SATELLITES	11
MULTIPATH	11
POSITION DILUTION OF PRECISION (PDOP)	12
SATELLITE ELEVATIONS	12
DIFFERENTIAL CORRECTIONS	12
OPERATION	13
COMMUNICATIONS WITH THE RECEIVER	13
Serial Port Default Settings	13
GETTING STARTED	14
INITIAL SETUP	14
8400HP RECEIVER SETTINGS	24
OMNISTAR VBS POSITION	26
SET SEED POINT	31
TERMINAL MODE	33
8400RTK	34
APPENDIX A	35
TECHNICAL SPECIFICATIONS	35
PERFORMANCE	35
ENVIRONMENTAL	35
POWER REQUIREMENTS	35
RF INPUT / LNA POWER OUTPUT	35
INPUT / OUTPUT DATA INTERFACE	36
Input / Output Connectors	36
Physical	36

OmniSTAR 8400HP User Manual

Port Pin-Outs.....	36
Power Connector.....	36
Serial RS232 Connector.....	37
CABLES.....	38
Power Cable.....	38
RS232 Serial Cable.....	38
APPENDIX B.....	39
COMMANDS.....	39
Bulb commands.....	39
set,.....	39
print, . . .	42
embulb, . . .	44
dmbulb, . . .	45
OmniStar commands.....	46
set,.....	46
print, . . .	51
Default parameters.....	55
Bulb parameters.....	55
OmniStar parameters.....	55
APPENDIX C.....	56
NMEA 0183 MESSAGE OPTIONS.....	56
NMEA 0183 MESSAGE FORMATS.....	57
ALM – GPS Almanac Data.....	57
GGA – GPS Fix Data.....	58
GLL – Geographic Position – Latitude/Longitude.....	59
GRS – GPS Range Residuals.....	59
GSA – GPS DOP and Active Satellites.....	60
GST – GPS Pseudorange Noise Statistics.....	61
GSV – GPS Satellites in View.....	62
RMC – Recommended Minimum Specific GPS Data.....	63
VTG – Course Over Ground and Ground Speed.....	64
ZDA – Time and Date.....	65
APPENDIX D.....	66
ACRONYMS USED IN THIS MANUAL.....	66
APPENDIX E.....	67
LIST OF COMMUNICATION SATELLITES.....	67
APPENDIX F.....	69
LIST OF REFERENCE STATIONS.....	69
APPENDIX G.....	73
RECEIVER SERVICE PROCEDURE.....	73
APPENDIX H.....	74

OmniSTAR 8400HP User Manual

OMNISTAR RECEIVER PROBLEM REPORT FORM	74
USER NOTES	75

LIST OF FIGURES

Figure 1: 8400HP back side	3
Figure 2: Zener Diode Connected.....	5
Figure 3: Multipath.....	12
Figure 4: View8400 start screen	15
Figure 5: View8400 Menu File option Connect.....	15
Figure 6: View8400 Select Com Port.....	16
Figure 7: View8400 receiver status.....	16
Figure 8: View8400 DGPS Correction Satellite Status.....	17
Figure 9: View8400 Configuration menu option DGPS service	17
Figure 10: View8400 Configuration menu option DGPS service	18
Figure 11: View8400 Subscription details	19
Figure 12: View8400 Firmware Version	20
Figure 13: View8400 GPS Satellites	21
Figure 14: View8400 Position	22
Figure 15: View8400 Select HP Port NMEA output in Configuration menu	22
Figure 16: View8400 NMEA output on HP Port.....	23
Figure 17: View8400 Select HP receiver settings	24
Figure 18: View8400 HP parameter.....	24
Figure 19: View8400 GPS receiver settings.....	26
Figure 20: View8400 Please switch to receiver port A	26
Figure 21: View8400 GPS receiver settings.....	27
Figure 22: View8400 GPS receiver options	28
Figure 23: View8400 Please switch back to the HP port.....	29
Figure 24: View8400 select Port NMEA output	29
Figure 25: View8400 Port A NMEA output.....	30
Figure 26: View8400 Select Set Seed Point	31
Figure 27: View8400 Set Seed Point	32
Figure 28: View8400 Select terminal Mode.....	33
Figure 29: View8400 Terminal.....	33
Figure 30: power Connector	37
Figure 31: Serial RS232 Connector	37
Figure 32: Reference stations and coverage area for EA-SAT and AF-SAT. .	67
Figure 33: Reference Stations and coverage area for AM-SAT and AP-SAT.	67
Figure 34: Reference stations and coverage area for OPTUS and MSV-ECW.	68

LIST OF TABLES

Table 1: 8400HP Connectors.....	3
Table 2: 8400HP LED indicators.....	3
Table 3: Power connector Specification	37
Table 4: RS232 Connector Specification	38
Table 5: NMEA 0183 messages available for the 8400HP.....	56
Table 6: Description of the ALM message.....	57
Table 7: Description of the GGA message.....	58

OmniSTAR 8400HP User Manual

Table 8: Description of the GLL message.....	59
Table 9: Description of the GRS message.....	59
Table 10: Description of the GSA message.....	60
Table 11: Description of the GST message.....	61
Table 12: Description of the GSV message.....	62
Table 13: Description of the RMC message.....	63
Table 14: Description of the VTG message.....	64
Table 15: Description of the ZDA message.....	65
Table 16: World-wide satellite frequencies and baud rates.....	67
Table 17: Reference stations on EA-SAT.....	69
Table 18: Reference stations on AF-SAT.....	70
Table 19: Reference stations on AP-Sat.....	70
Table 20: Reference stations on AM-Sat.....	71

Introduction

About This Manual

This manual has been produced to assist the typical user with the installation and operation of the OmniSTAR 8400HP DGPS Receiver.

System Features

The OmniSTAR 8400HP DGPS Receiver is part of the Fugro worldwide DGPS Service. The Fugro service is a full-time differential GPS (DGPS) broadcast system, delivering corrections from an array of GPS reference stations located around the globe. Reference stations provide industry standard formatted corrections to Network Control Centres (NCC's) at strategic geographic locations, where the corrections are decoded, checked, and repackaged in a highly efficient format for broadcast. The data is modulated onto a RF carrier that is then uplinked to an L-band communications satellite.

The signals are received at the user's location by an antenna, demodulated by a receiver, and are made available, after selection of the desired individual reference site's data set, as corrections for use in a GPS, differential-capable, receiver.

The OmniSTAR 8400HP series of receivers support the following OmniSTAR® services:

HP, this is the High Performance service where dual frequency GPS carrier phase measurements are used in an intelligent and innovative way to create wide area positioning results of decimetre accuracy and performance.

XP, this is the High Performance service where dual frequency GPS carrier phase measurements are used with precise orbit and precise clock information from the satellite. For XP no Ground reference stations are needed

HPXP, Here the solution of HP and XP are merged to optimize performance and redundancy

VBS, this is the Virtual Base Station service where single frequency GPS code phase measurements are used to create RTCM corrections data optimised for the users current position.

Receiver Features

The OmniSTAR 8400HP receiver has the following features:

- 20 channel GPS L1/L2 C/A and P-Code Carrier

OmniSTAR 8400HP User Manual

- Fast GPS reacquisition
- Fully field-upgradeable firmware
- Low power consumption

The following options are available for the 8400HP:

- L1 plus OmniSTAR VBS
- L1/L2 plus OmniSTAR HP
- L1/L2 plus RTK Note: Not supported by Omnistar.
- 5 Hz RAW data and position output rates
- 10 Hz RAW data and position output rates
- Internal Memory
- Advanced Multipath reduction, GPS L1
- Advanced Multipath reduction, GPS L1+L2

Housing

The 8400HP receiver is 159 mm wide, 172 mm deep, 88 mm high, and weighs 1.4 kg (Figure 1). The casing allocates space for two non-removable, on-board Li-Ion batteries, a power board, and two Euro cards. One of those cards is the GPS L1 receiver and the other is the OmniSTAR receiver.

The enclosure offers protection against environmental conditions and RF interference. In addition, it provides an easy-to-use interface to the GPS card's data, power and status signals and a rugged, water, shock and vibration resistant housing for outdoor applications.

Interfaces

The 8400HP provides the following interfaces:

- 2 serial ports with LEMO-brand connectors
- GPS antenna and power port
- LED indicators to provide status information
- 2 Internal batteries

Accessories

The following accessories are included with the 8400HP:

- 1 power adapter cable
- 1 straight serial port cable
- GPS antenna
- Antenna mounting bracket
- A CD containing PC utilities and product documentation

OmniSTAR 8400HP User Manual

For technical specifications on the 8400HP, please see Appendix B.



Figure 1: 8400HP back side

Connector	Function
PWR	Power connector
A	GPS serial port connector
HP	HP serial port connector
GPS ANT	GPS/L-band antenna connector

Table 1: 8400HP Connectors

LED	Function
STAT	Status, # GPS satellite tracked
REC	Data recording indicator
BATT	Battery charge and power source
RX	OmniSTAR Satellite lock indicator
“Blue”	Bluetooth indicator

Table 2: 8400HP LED indicators

Installation and Set Up

Installation Considerations

Before commencing installation of the OmniSTAR 8400HP in a vehicle or aircraft, the following should be considered:

- Determine the preferred location for the unit. Consider cable length, connector attachment space (cable bend radius), stowing excess cable, moisture, chemical corrosion, vibration and heat exposure.
- Before drilling holes, consider using existing hardware and locations where equipment was previously installed. Avoid drilling holes that may damage other equipment (e.g. structural frame members, electrical cables or fluid lines).
- High vibration and high temperature locations should be avoided whenever possible.
- In applications where vibration exceeds 5Gs acceleration, shock mounts are required. (Refer to Customer support for mounting recommendations).
- Vehicle primary power has voltages that may be harmful to personnel and equipment. Disconnect the battery cable from the battery –ve (negative) terminal before making connection to any power terminal within the vehicle.

Counter Electromagnetic Force (CEMF)

A potential problem inherent in any installation of electronic systems within a vehicle is Counter Electro-magnetic Force (CEMF).

CEMF is caused when relays or solenoids, connected to the vehicle DC power distribution, are de-energised. The voltage produced may exceed – 400 volts.

CEMF is produced by equipment such as the following:

- **Electric fan brakes**
- **Air conditioners**
- **Starter relays**
- **Electric pump relays**

CEMF is more than sufficient to damage or cause erratic operation of any electronic system that is also connected to the same vehicle DC power supply. CEMF can be eliminated by installing diodes at the relays and solenoids that cause the problem, and more importantly at the power supply cable connections on the receiver.

A 47V, 5W, Zener diode (1N5368 or equivalent) should be connected between the receiver +ve (positive) power input terminal and ground, as illustrated in Figure 2.




Figure 2: Zener Diode Connected

Cable Installation

Cables must be correctly installed for optimum system operation. Therefore, the following should be noted:

- Do not route an L-Band receiver remote antenna cable with the cabling of any other radio system. This may cause interference between both systems.
- If at all possible, do not run L-Band receiver antenna cables parallel to other radio system cabling closer than 30 centimetres.
- If cables must cross, ensure that they cross at an angle of 90°. This minimises the possibility of interference.
- As far as is practicable, ensure that cables and I/O connectors are unique and fit only in their allocated location.
- Avoid routing cables along-side power generator cabling and other high electrical noise sources. This can cause interference.
- Do not kink or force cables into sharp bends that may damage the cables and cause system failure.
- After installation, ensure that excess cable is looped and clamped or tied safely away from any control cables, fuel lines, hydraulic lines or moving parts.
- When stowing over length cables, form loops not less than 150 mm minimum cable bend radius.
- Cable routing must avoid high temperature exposure (e.g. exhaust manifold).

Additional Features and Information

This section contains information on the additional features of the 8400HP receiver and an explanation of the Led functions.

Sleep Mode

In sleep mode, the power board and Bluetooth module will continue to draw power from the batteries, causing the batteries to drain over time. Follow these steps to put the 8400HP into sleep mode:

1. Turn on your receiver.
2. Press and hold the receiver's **power** key for more than four seconds and less than eight seconds. The STAT LED will be orange. The receiver enters Sleep Mode.
3. Any activity on the RS232 port will turn the receiver on.



If you press and hold the power key for more than 14 seconds, it will be ignored. This protects receiver operation against stuck keys.

Put the receiver in Zero Power Mode to prevent the draining of the battery.

Zero Power Mode

When your receiver is off, even in Sleep Mode, the power board will continue to draw power from the batteries. This means that if you fully charge your receiver, turn it off and store it, the receiver will drain its battery power in less than two months. To stop the power board from draining the batteries, you can put your receiver in Zero Power Mode:

1. Turn on your receiver.
2. Press and hold the **power** key for more than 8 seconds, but less than 14 seconds.
3. Release the **power** key when the STAT and REC LED's all become red. When the LED's turn off, your receiver will be in Zero Power Mode.
4. Press the **Reset** key for about one second to return to Normal mode.



When the internal batteries have completely discharged and no external power is connected, the receiver will go into Zero Power Mode automatically to prevent the batteries from over discharging.

Status Indicators

The 8400HP has LED indicators that provide the status of the 8400HP. See Table 2: 8400HP LED indicators on page 3.

Status LED

- When the receiver is on and no GPS satellites are tracked, the STAT LED will blink red.
- When satellites are tracked, the STAT LED will produce one green blink for each tracked satellite.

Record LED and FN Key

- During the first second of pressing the **FN** key, the REC LED is orange.
- Pressing and holding the FN key for more than five and less than eight seconds will turn the baud rate of serial port A to 9600. After about five seconds of pressing the FN key, the REC LED becomes red. Release the FN key while the REC LED is red (during the next three seconds).
- Pressing and holding the FN key for more than eight seconds has no impact.
- After loading new firmware or clearing the receiver's NVRAM, the receiver checks its internal file system. During this operation, the REC LED flashes orange, and the file system is not accessible for CDU (control display unit) applications or for data recording. This operation may require from fractions of a second to several minutes, depending on the circumstances and the amount of internal memory.

Bluetooth LED

The colour of the BT LED indicates the level of activity at the Bluetooth communication link:

- Blue flashes – the Bluetooth module is on but no connection is established.
- Solid blue light – the Bluetooth module is on and a connection is established.
- No light – the Bluetooth module is off

If no Bluetooth module is installed the LED will flash when Blue tooth is switched on.

Battery LED

The colour of the BATT LED indicates the level of internal battery charge in the receiver:

- Green – indicates greater than 85% charge
- Orange – indicates an intermediate charge
- Red – indicates less than 15% charge

The pattern of blinks of the BATT LED also indicates the source of power:

- Solid light – an external power supply is used and the batteries are not being charged.
- Blinking once a second – the batteries are being charged.

Omnistar 8400HP User Manual

- Blinking once every five seconds – the receiver uses the internal batteries for power.
- Not blinking – the receiver is in Zero Power Mode or the internal batteries are completely discharged and no external power is connected.



When the internal batteries have completely discharged and no external power is connected, the receiver will go into Zero Power Mode to prevent the batteries from over discharging.

RX LED

The colour of the RX LED indicates the status of the differential corrections for the Omnistar board.

For the Omnistar board when in operation mode:

- Blinks green – the receiver is searching for the selected Omnistar satellite.

Solid green – the Omnistar satellite is locked.

Clear NVRAM

The receiver's Non-Volatile Random Access Memory (NVRAM) holds data required for satellite tracking, such as ephemeris data and receiver position. The NVRAM also keeps the current receiver's settings, such as active antenna input, elevation masks and recording interval, and information about the receiver's internal file system.

Even though clearing the NVRAM is not a common (nor normally a recommended) operation, there are times when clearing the NVRAM can eliminate communication or tracking problems. Clearing the NVRAM in your receiver can be interpreted as a "soft boot" in your computer.

After clearing the NVRAM, your receiver will require some time to collect new ephemeris and almanacs (around 15 minutes).

Clearing the NVRAM of your receiver will not delete any files already recorded in your 8400HP's memory. However, it will reset your receiver to factory default values.

In addition, the NVRAM keeps information about the receiver file system. Note that after clearing the NVRAM, the receiver's STAT LED will flash orange for a few seconds indicating that the receiver is scanning and checking the file system.

Use Keys to Clear NVRAM

1. Press the **power** key to turn off the receiver.
2. Press and hold the **FN** key.
3. Press and hold the **power** key for about one second. Release the **power** key while continuing to hold the **FN** key.
4. Wait until the STAT and REC LED's are green

OmniSTAR 8400HP User Manual

5. Wait until the STAT and REC LED's blink orange.
6. Release the **FN** key while the STAT and REC LED's blink orange.

Use View8400 to clear NVRAM

1. Connect the receiver to a computer via the HP port
2. Select in the Configuration menu the GPS receiver settings
3. Change cable from port HP to port A
4. Press Clear NVRAM button

Antenna Location

Antenna positioning is critical to system performance.

The following conditions must be met for optimum system performance:

- Antenna must be mounted at least 1.5 metres away from transmitting antennas of any frequency. Closer positioning may cause saturation of receiver RF circuits.
- The antenna should be mounted at the highest practical point that will give a good view of the horizon and be as near level as possible.
- The antenna must be located along the vehicle centre-line, or at a relevant reference point on the vehicle.

Power Supply Requirements

The 8400HP contains an internal power board that manages receiver power and battery charging, and is connected to the receiver board and the batteries. The power board receives power from the internal batteries, even when the receiver is turned off. This feature allows the internal batteries to charge, regardless of the receiver's status (on or off). To prevent the batteries from discharging when the receiver is stored, put the receiver in Zero Power Mode. A tightly regulated input supply to the 8400HP is not required, as long as it falls within the input range +8 to +28VDC.



If the voltage supplied is below the minimum specification, the receiver will suspend operation. If the voltage supplied is above the maximum specification, the receiver may be permanently damaged, voiding your warranty.

Operating considerations

The 8400HP is a high-quality positioning device. The accuracy that the user can obtain depends on several factors, including:

- Number of visible satellites
- Multipath
- Dilution of Precision (DOP)
- Satellite elevations
- Differential correction
- Distance to reference station network

Number of visible satellites

A minimum of four satellites is required to calculate a 3-dimensional position. In general it can be said that every increase in the number of visible satellites will result in an increase in the system's accuracy. As the GPS satellites orbit around the earth the number of visible satellites will change in time. The GPS constellation has been designed so as to provide a minimum of 4 visible satellites at any location at all times. The number of visible satellites can decrease due to blockage by objects such as trees and buildings.

Multipath

It is possible for satellite signals to reflect off large nearby objects such as buildings, cars or even the ground, thereby resulting in an erroneous distance measurement. This phenomenon is known as multipath. Multipath can cause significant errors in the position determination and it is therefore important to place the receiver in an environment, which is free of large reflective surfaces. It is also recommended to mount the receiver directly onto a surface, while maintaining a clear view of the sky in all directions.




Figure 3: Multipath

Position Dilution of Precision (PDOP)

The Position Dilution of Precision (PDOP) is a measure of the satellite geometry. The lower the PDOP value, the more accurate the GPS position will be.

Satellite elevations

The signal from a satellite that is low on the horizon will travel a greater distance through the atmosphere. This results in a lower signal strength and a delayed reception, thereby causing erroneous and noisy data. By default the 8400HP is configured to ignore any satellites that have an elevation angle lower than 5° for VBS and lower than 8° for HP.

Differential corrections

For accurate positioning it is essential that the differential corrections are received. In order to ensure reception of the OmniSTAR satellite signal the line of sight towards the satellite must not be blocked by objects such as trees and buildings.

Multipath reflections can cause destructive interference, thereby significantly decreasing the signal strength. It is therefore recommended to mount the 8400HP antenna directly onto a surface in a reflection free environment.

Although the 8400HP has been designed to provide optimal system performance under most circumstances, it is possible, due to the nature of radio communications that the system performance degrades due to local interference sources.

Operation

Before operating the receiver for the first time, ensure that you have followed the installation instructions.

Communications with the Receiver

Communication with the receiver is straightforward, and consist of issuing commands through the communications ports from an external serial communication device. This could be either a terminal or an IBM-compatible PC that is directly connected to the receiver serial port. For more information about commands and logs that are useful for basic operation of the receiver, go to Appendix D.

Serial Port Default Settings

The receiver communicates with your PC or Terminal via serial port. For communication to occur, both the receiver and the operator interface have to be configured properly. The receiver's port A and HP port default settings are as follows:

- **115200 BPS, no parity, 8 data bits, 1 stop bit, no handshaking.**

The data transfer rate you choose will determine how fast information is transmitted. Take for example a log whose message byte count is 96. The default port settings will allow 10 bits/byte. It will therefore take 960 bits per message. To get 10 messages per second then will require 9600 BPS. Please also remember that even if you set the bps to 9600 the actual data transfer rate will be less and depends on the number of satellites being tracked, filters in use, and idle time. It is therefore suggested that you leave yourself a margin when choosing a data rate.

Getting Started

The purpose of this section is to get you started with the 8400HP as quickly as possible. The guide will address receiving the satellite data carrier, and then checking the functionality and status of the HP Process.

Generally when the receiver is supplied to you it will be configured for the mode and data link(s) you have subscribed to. In most cases to get up and running will be a case of connecting the appropriate cables and applying power to the system.

Included with your receiver is the View8400 application. This application allows you to check the status of the receiver and configure the GPS and HP receiver.

Initial Setup

Refer to the following diagrams, as you will need to assemble all the required items.

- OmniSTAR 8400HP Receiver
 - GPS/L-band Antenna
 - Antenna Cable
 - Power Cable
 - HP Port Cable
1. Install the antenna where it has a clear view of the sky in the direction of the satellite.
 2. Connect the antenna cable between the antenna and the 8400HP (TNC connector labelled 'GPS ANT').
 3. Connect the power cable to a suitable 8-28 VDC power source.
 4. Turn on the receiver: press and hold the green **power** button for about 0.5 seconds and release it.
 5. Check the colour of the BATT LED to verify the receiver has sufficient power.
 6. Connect the receiver to the serial port of a computer via the HP port and start the View8400.exe application. View8400 is available on the supplied CD or on the www.omnistar.nl website. The following screen will appear, Figure 4: View8400 start screen.

OmniSTAR 8400HP User Manual




Figure 4: View8400 start screen

7. Select File and Connect.



Figure 5: View8400 Menu File option Connect

The Select Com port screen enables you to select the COM port of the computer and select a different baud rate, Figure 6: View8400 Select Com Port. The 8400HP receiver uses two ports port A for the GPS and the HP port for the HP processor. The 'use two comports' selection box can be used if both ports are connected to the computer. When the 'Autoconnect' option is ticked the application will use the same settings next time the application is started.

If the Autoconnect option was used before and the receiver is on a different COM port, please use disconnect in the File menu option and connect to get the Select Com port window.




Figure 6: View8400 Select Com Port

When the connection is established the View8400 screen will show the current status of the receiver.




Figure 7: View8400 receiver status

OmniSTAR 8400HP User Manual

The separate information blocks are:

- DGPS Correction Satellite Status (Figure 8)
- Subscription details (Figure 11)
- Firmware version (Figure 12)
- GPS Satellites (Figure 13)
- Position (Figure 14)



Figure 8: View8400 DGPS Correction Satellite Status

The OmniSTAR 8400HP receiver is configured for the area of work. For Europe this is the EA-Sat with frequency 1535.1525 MHz. The DGPS Correction Satellite Status window will show the current status of the satellite link. Appendix E contains a list of OmniSTAR Satellites. If the receiver is used in a different area of the world a different satellite must be selected.

8. Selecting 'DGPS service' in the menu option 'Configuration' opens the Select DGPS service window.



Figure 9: View8400 Configuration menu option DGPS service



Figure 10: View8400 Configuration menu option DGPS service

11. In the Satellite selection box all available OmniSTAR satellites can be selected.
12. The receiver is ready to work when the receiver is logged on to the correct satellite signal and the subscription is valid.
13. The Subscription details window (Figure 11) shows the status of both the VBS and the HP subscription. The warnings at the right of the window will show the errors if the subscription does not work. The 'Needs Update' warning is generated when the receiver is switched after a long period of inactivity or after a change of satellite service. The 'Needs update' warning will disappear after the receiver has received the OmniSTAR Almanac and site table from the satellite link.

OmniSTAR 8400HP User Manual




Figure 11: View8400 Subscription details

14. If one of the other warnings is active you will have to contact the OmniSTAR office for an activation.



Figure 12: View8400 Firmware Version

15. The OmniSTAR activation is sent by satellite to the receiver, which is identified by the OmniSTAR serial number.
16. The receiver must be switched on and be receiving the satellite signal at the moment the subscription is sent.
17. The GPS Satellites window will show which GPS satellites are tracked and supply all information about the satellites.

PRN	EL	AZ	CA	P1	P2	TC	SS
23	20	168	42	25	26	3	0
1	49	72	47	34	34	7	0
28	6	256	38	7	6	45	0
24	42	294	49	31	32	33	0
25	17	92	40	22	21	2	0
7	35	300	48	29	29	2	0
20	68	248	48	33	33	110	0
11	65	142	50	34	34	14	0
31	127	510	49	32	32	121	6
14	19	40	42	27	26	10	0

Figure 13: View8400 GPS Satellites

Position (dd° mm' ss")			Position (dd° mm' ss")			ECEF		
Date / Time								
06/06/2005 09:25:28								
Latitude (dd° mm' ss")	Longitude (ddd° mm' ss")	Altitude (m)						
N 52.06543464	E 4.40514823	58.652						
Velocity Lat (m/s)	Velocity Lon (m/s)	Velocity Height (m/s)						
0.012	0.012	0.033						
STD dev of Latitude (m)	STD dev of Longitude (m)	STD dev of Height (m)						
0.04	0.043	0.077						
Number of L1 Observations	Number of L2 Observations	PDOP						
3	3	1.36						
Age of Data (sec)	Mode							
7	HP							

OmniSTAR 8400HP User Manual

Figure 14: View8400 Position

The position window will show the current position. The tabs can be selected if you want to show the position information in a different format.

18. Enable the NMEA output on the HP port. Select in the Configuration menu option, NMEA output on HP Port.



Figure 15: View8400 Select HP Port NMEA output in Configuration menu

19. The following screen will appear.




Figure 16: View8400 NMEA output on HP Port

If any message is switched on at startup of View8400, this message will be ticked and the output rate becomes visible.

20. When View8400 is closed the HP Port output will be as selected in the right figure.

8400HP receiver settings

In the Configuration menu option HP receiver settings the receiver HP parameter window will appear.



Figure 17: View8400 Select HP receiver settings



Figure 18: View8400 HP parameter

- Smooth mode, HP filter options
- VBS seeding, at start-up the VBS position is used as start position for the HP process.
- Static initialisation, if the receiver is static this mode will improve the initialisation time.

OmniSTAR 8400HP User Manual

- Autoscans search mode, the receiver can use the Low and High power OmniSTAR satellites. In high mode the receiver will use the OmniSTAR spotbeams.
- Frequency search span, the receiver searches for the OmniSTAR satellite signal using the defined span. If an interfering satellite signal is close to the OmniSTAR frequency the receiver can lock on to that frequency. To prevent this the span can be reduced.
- Engine mode, the receiver can be set to 'HP' or 'XP' mode. In 'HP' mode the receiver uses the Fugro network of reference stations for the HP positioning. In 'XP' mode the receiver uses the precise orbits which are broadcasted by the OmniSTAR satellites.

OmniSTAR VBS position

The OmniSTAR 8400HP receiver can be configured to output HP corrected GPS positions over the HP port and simultaneously output VBS corrected position through port A. The receiver must have a valid VBS subscription, the View8400 Subscription Details screen (Figure 11, page 19) shows the current status of the subscription.

With the option 'GPS receiver settings...' in the Configuration menu the GPS receiver can be configured for VBS.



Figure 19: View8400 GPS receiver settings

If you are using a single COM port, the application will show the following screen.




Figure 20: View8400 Please switch to receiver port A

The serial cable will have to be disconnected from the HP port and connected to port A. Please press OK after the cable is switched.

The GPS receiver settings window shows the current GPS receiver configuration.




Figure 21: View8400 GPS receiver settings

- The Positioning mode can be either standalone or DGPS.
- The DGPS max age only applies for the VBS position.
- The Bluetooth option is not available in all 8400HP receivers, if it is not available the selection switches the blue LED off.
- If you require a NMEA output rate higher than 1 Hz, the Raw update and Position update rate has to be changed to the required interval time. In the GPS receiver options you can check if a higher update rate is available. The receiver options in Figure 22: View8400 GPS receiver options show the maximum update rate of the used receiver, this can be upgraded to 10 Hz.

With the GPS receiver options button you can request a list of the available receiver options.

Option name	Current	Purchased	Leased	Date
GPS	yes	yes	no	
GLONASS	----	no	no	
L1	yes	yes	no	
L2	yes	yes	no	
Cinderella	yes	yes	no	
Position update rate (Hz)	1	1	0	
Raw data update rate (Hz)	1	1	0	
Code differential Base	yes	yes	no	
Code differential Rover	yes	yes	no	
RTK Base	yes	yes	no	
RTK Rover (Hz)	1	1	0	
Memory (MB)	0	0	0	
Co-Op Tracking	yes	yes	no	
1PPS timing signal	0	0	0	
Event Markers	0	0	0	
In-Band Int. Rejection	----	0	0	
Multipath Reduction	no	no	no	
Frequency Input	no	no	no	
Freq. Lock and Output	no	no	no	
Serial Port A (Kbps)	460	460	0	
Serial Port B (Kbps)	0	0	0	
Serial Port C (Kbps)	460	460	0	
Serial Port D (Kbps)	0	0	0	
Infrared Port	----	yes	no	
Parallel Port	----	no	no	
Sp. Sp. Freq. Hop.	----	no	no	

Figure 22: View8400 GPS receiver options

The options can be purchased or leased if you want to upgrade your receiver. With the 'Load' button the "jpo" upgrade file can be loaded in to the receiver. The upgrade file name contains the internal GPS receiver serial number. This number is necessary if you request a receiver upgrade. The 'Save' button will create a text file with all options. The 'Exit' button is used to close the window.

The options determine the receiver capabilities. For a receiver to work with VBS the Code differential Base and Rover options are necessary. If these options are available you can configure the receiver to output differential corrected positions from port A.

After configuring the GPS receiver press OK. Figure 23: View8400 Please switch back to the HP port will appear if you are using a single COM port connection.



Figure 23: View8400 Please switch back to the HP port

Change the serial cable first before pressing 'OK', the application does send a configuration command to the HP port after 'OK' is pressed.

The NMEA output of port A can be selected in the Configuration menu option 'NMEA output'. Select Port A and connect the serial cable to port A.



Figure 24: View8400 select Port NMEA output

The Port A output options window will appear and the required NMEA messages can be selected.




Figure 25: View8400 Port A NMEA output

Set Seed Point

The OmniSTAR HP system has a typical dynamic convergence time of 20 minutes. To improve the convergence time the OmniSTAR HP system can be started from a known position or seed point.



Figure 26: View8400 Select Set Seed Point

The Set Seed point window will appear, Figure 27: View8400 Set Seed Point. The application will read the current seed point which is stored in the receiver and show the values in the position fields. If the receiver does not have a seed position the fields will be empty.

The following options are available, see Figure 27: View8400 Set Seed Point:

1. Send seed point reset
 2. Get current position and Std dev
 3. Store seed point in file
 4. Load seed point from file
-
1. Send seed point reset will reset the stored seed point in the receiver.
 2. Get current position and Std dev, read the current position.
 3. Store seed point in file, the position can be stored in a "ksp" "known start position" file.
 4. Retrieve the seed position from a "ksp" file.

These functions can be used

- a) Want to start work quickly
- b) If you want to stop working and continue to work the next day starting at the last point.




Figure 27: View8400 Set Seed Point

Terminal Mode

The View8400 application has a terminal option that can be used to send commands direct to the HP port of the receiver.




Figure 28: View8400 Select terminal Mode



Figure 29: View8400 Terminal

If you are connected with the receiver using a single COM port, the commands will be sent to the HP port. If you are connected using two COM ports you can select the HP or the GPS port.

The terminal can be used to send text files that can contain a series of commands. Appendix B contains a list of the commands.

8400RTK

The 8400HP receiver can be used as a RTK rover and base station. These options will have to be purchased separately; this can be verified in the GPS receiver options. In the OmniSTAR VBS position paragraph it is shown how the options can be read from the receiver.

The 8400RTK base station can output RTCM messages from port A. The commands for this configuration have to be send to Port A:

```
dm
%%set,/par/rover/mode/,off
%%set,/par/base/mode/,off
%%set,/par/pos/mode/cur,sp
%%set,/par/ref/pos//geo,{W84,N52d5.7860586m,E4d24.3687564m
,55.782}
em,,rtcm{/18:1,/19:1,/20:1,/21:1,/22:1,/3:10}
```

The 8400RTK rover can output the GPS fixed position, GGA quality indicator value '4', from both the HP port and port A.

8400RTK Rover, NMEA from HP Port:

```
dm,/dev/ser/b
dm
%%set,/par/dev/ser/b/echo,/dev/ser/a
```

8400RTK Rover NMEA from port A

```
dm
dm,/dev/ser/c
em,/dev/ser/c,/msg/nmea/GGA
em,,/msg/nmea/GGA
%%set,/par/pos/mode/cur,pd
%%set,/par/dev/ser/a/imode,rtcm
```

The last command sets the port A input mode to RTCM, this means that the receiver does not accept commands anymore. To configure the receiver for HP mode a Clear NVRAM has to be performed using the power and FN key first, see Clear NVRAM on page 9. After this the View8400 can be used to configure the 8400HP receiver.

Appendix A

Technical Specifications

PERFORMANCE

Position Accuracy ¹	VBS: σ 25 cm (X,Y) 50 cm Z HP: Seeding: σ 5 cm (X,Y) 10 cm Z Static σ_{3D} 30cm, 10 min Dynamic σ_{3D} 30cm 25 min RTK:H: 10 mm + 1ppm V: 15 mm + 1ppm
---------------------------------------	---

GPS satellite Reacquisition	< 1 sec
------------------------------------	---------

Data Rates	1 Hz (default), 5, 10, 20 Hz optional
-------------------	---------------------------------------

ENVIRONMENTAL

Operating Temperature	-30°C to +60°C with batteries
------------------------------	-------------------------------

Storage Temperature	-40°C to +75°C with batteries
----------------------------	-------------------------------

Humidity	Not to exceed 95% non-condensing
-----------------	----------------------------------

POWER REQUIREMENTS

Voltage	+8 to +28 VDC (for work) +9 to +28 VDC (for charge battery) Minimum Charge current \leq 2Amp
----------------	--

Power consumption	OmniSTAR Mode 5.1 W
--------------------------	---------------------

RF INPUT / LNA POWER OUTPUT

Antenna connector	TNC female, 50 Ω nominal
--------------------------	---------------------------------

¹ Typical values. Performance specifications are subject to GPS system characteristics, U.S. DOD operational degradation, ionospheric and tropospheric conditions, satellite geometry, baseline length and multipath effects.

OmniSTAR 8400HP User Manual

impedance

RF Input Frequencies

1575.42 MHz (L1), 1227.60 MHz (L2),
1525 MHz – 1559 MHz (L-Band)

LNA Power

+2.7 to +12 VDC; 15 mA @ 5.0
typical

INPUT / OUTPUT DATA INTERFACE

Electrical Specification

RS232

Baud Rate

300, 1200, 4800, 9600 19200, 57600,
115200(default) bps

Input / Output Connectors

GPS ANT

TNC female jack, 50 Ω nominal
Impedance, + 5.42 VDC (output from
8400HP to antenna/LNA)

Physical

Size

W: 195 x H: 88 x D: 172 mm

Weight

1.4 kg

Enclosure

Aluminium

Port Pin-Outs

Power Connector

The power connector (Figure 30) is a sealed receptacle, 5 pin W.W. Fisher bulkhead plug.

Table 3 gives power connector specifications.



Figure 30: power Connector

Number	Signal Name	Dir	Details
1	Power_INP	P	6 to 28 Volts DC input
2	Power_INP	P	6 to 28 Volts DC input
3	Power_GND	P	Ground, power return
4	Power_GND	P	Ground, power return
5			Not Used

Table 3: Power connector Specification

Serial RS232 Connector

For ports A and HP. The RS232 connectors (Figure 31) are sealed receptacle, 7 pin W.W. Fisher bulkhead plugs.



Figure 31: Serial RS232 Connector

OmniSTAR 8400HP User Manual

Table 4 gives the RS232 connector specification.

Number	Signal Name	Dir	Details
1	Power_OUT	P	Power Output (Supplied Voltage)
2	GND	-	Signal ground
3	CTS	I	Clear to send
4	RTS	O	Request to send
5	RXD	I	Receive data
6	TXD	O	Transmit data
7			Not used

Table 4: RS232 Connector Specification

Cables

Power Cable

The power cable supplied with the 8400HP is a 5-pin W.W. Fisher Series 102 plug to 2-way SAE connector.

With the power cable a power charger is supplied which can be used as an external power source or as the charger for the internal batteries. This unit converts the alternating current (AC) normally supplied from an electrical outlet to a direct current (DC), which is used to charge the batteries and power the receiver.

- Input voltage – between 90 and 264 V AC
- Frequency of input power – between 47 Hz and 63 Hz
- Output voltage – 12 V DC @ 2.5 A (30 W)

RS232 Serial Cable

The RS232 serial cable is used to the receiver's port A or port HP and an external device (hand-held controller or computer).

The cable is a sealed DB-9 female plug to a sealed 7-pin W.W. Fisher plug.

Appendix B

Commands

Following are the commands with detailed descriptions that can be sent to the 8400HP.

```
COMMANDS FOR HP-BULB RECEIVER { ver 1.0 pl }
```

```
*****
```

Bulb commands

```
*****
```

set,...

```
set,/par/bulb/init/fctr,mode
```

```
{Set all the parameters to the default factory value}
```

mode:

```
y      {};  
on     {};  
yes    {};  
  
n      {};  
off    {};  
no     {}.
```

```
set,/par/bulb/reset,mode
```

mode:

```
y      {};  
on     {};  
yes    {};  
  
n      {};  
off    {};  
no     {}.
```

OmniSTAR 8400HP User Manual

```
set,/par/bulb/conf,param
```

param:

```
off    {};  
on     { automatic configuration of system }.
```

```
set,/par/bulb/mode,param
```

param:

```
off    { mode OFF };  
omni   { mode OmniStar }.
```

```
set,/par/bulb/ant/pwr,mode
```

mode:

```
off    { a power of the antenna is turn off };  
on     { a power of the antenna is turn on }.
```

```
set,/par/bulb/dev/ser/b/rate,param
```

```
{ Serial port Baud Rate }
```

param:

```
300    {};  
600    {};  
1200   {};  
2400   {};  
4800   {};  
9600   {};  
19200  {};  
38400  {};  
57600  {};  
115200 {};  
153600 {}.
```

```
set,/par/bulb/dev/ser/b/imode,param
```

```
{ Serial port Input Mode }
```

param:

```
cmd    { command mode };  
jps    { JPS messages input mode };  
echo   { echo mode }.
```

OmniSTAR 8400HP User Manual

```
set,/par/bulb/dev/ser/b/eoff,string
```

```
{ Ech-off sequence parameter (arbitrary string  
  comprising up to 32 characters) }
```

```
For example: #BULB# {set,bulb/dev/ser/a/eoff,"#BULB#"}
```

```
set,/par/bulb/dev/ser/b/echo,param
```

```
{ Serial port Echo Mode }
```

param:

```
    /dev/null      { disable echo mode };  
    /dev/ser/a     { echo in port A };  
    /dev/ser/b     { echo in port B }.
```

```
set,/par/bulb/spectr/spec,mode
```

mode:

```
    off      { spectrum OFF };  
    on       { spectrum ON }.
```

```
set,/par/bulb/spectr/carrfrq,frequency
```

frequency:

```
    in Hz    { carrier frequency }.
```

frequency range:

```
    Omni:                1525000000 Hz - 1559000000 Hz
```

for example:

```
    1535152500
```

```
set,/par/bulb/spectr/spanfrq,frequency
```

frequency:

```
    in Hz    { frequency span }.
```

frequency range:

OmniSTAR 8400HP User Manual

0 Hz - 100000 Hz

for example:

100000

set,/par/bulb/spectr/filfrq,**frequency**

frequency:

in Hz { frequency filter }.

frequency range:

0 Hz - 10000 Hz

for example:

10000

set,/par/bulb/spectr/detnum,**number**

number:

{ }.

number range:

1 - 500

for example:

500

print,...

print,/par/bulb:on

print,/par/bulb/conf:on

print,/par/bulb/mode:on

print,/par/bulb/spectr:on

```
print,/par/bulb/spectr/param
```

param:

```
spec    { spectrum ON/OFF };  
carrfrq { carrier frequency };  
spanfrq { frequency span };  
filfrq  { frequency filter };  
detnum  {}.
```

```
print,/par/bulb/rcv/ver:on
```

```
print,/par/bulb/rcv/ver/param
```

param:

```
main    { firmware version };  
boot    { boot-loader version };  
hw      { hardware version };  
board   { board version }.
```

```
print,/par/bulb/rcv/uptime:on
```

```
{ time since last re-boot: day-hours-minutes-seconds,  
  e.g. 0d01h31m12s }.
```

```
print,/par/bulb/rcv/id:on
```

```
{ receiver ID }.
```

```
print,/par/bulb/rcv/model:on
```

```
{ receiver model }.
```

```
print,/par/bulb/rcv/mem:on
```

```
{ size of RAM in kilobytes }.
```

```
print,/par/bulb/rcv/sn:on
```

```
print,/par/bulb/dev/thermo/out
```

```
{ query receiver board temperature , [Celsius] }.
```

OmniSTAR 8400HP User Manual

```
print,/par/bulb/dev/ser/a/param
```

```
print,/par/bulb/dev/ser/b/param
```

param:

```
rate    { Serial port Baud Rate };
imode   { Serial port Input Mode };
echo    { Serial port Echo Mode };
eoff    { Echo-off sequence parameter }.
```

```
print,/par/bulb/ant/param
```

param:

```
pwr     { status of power antenna };
dc      { status of external antenna connection:
         off - ext antenna will not draw any DC
         normal - ext antenna draws normal DC
         overload - ext antenna draws current
         higher than expected }.
```

```
print,/par/bulb/pwr/param
```

param:

```
extant  {query external antenna voltage,
         [volts] };
extantdc {query external antenna current, [mA] }.
```

```
print,bulb/out/dev/ser/a
print,bulb/out/dev/ser/a:on
print,bulb/out/dev/ser/b
print,bulb/out/dev/ser/b:on
```

```
{ This message set comprises messages enabled for
  output to the corresponding serial port (only for
  "jps" and "nmea" messages) }.
```

embulb,...

```
embulb,/dev/ser/b,jps/message
```

message:

```
RT      { Receiver Time };
RD      { Receiver Date };
```

Omnistar 8400HP User Manual

```
PG      { Geodetic Position };
PV      { Cartesian Position and Velocity };
DP      { Dilution of Precision (DOP)Parameters };
SI      { Satellite Indices };
EL      { Satellite Elevations };
AZ      { Satellite Azimuths };
EC      { C/A Carrier to Noise Ratio };
E1      { P/L1 Carrier to Noise Ratio };
E2      { P/L2 Carrier to Noise Ratio };
TC      { Time Since Last Loss-of-Lock on
particular C/A signal };
SS      { Satellite navigation status };
EE      { Epoch End };
ET      { Epoch Time };

gt      { GPS Time << from Omnistar HP };
po      { Cartesian Position << from Omnistar HP};
pg      { Geodetic Position << from Omnistar HP};
ve      { Cartesian Velocity << from Omnistar HP};
pv      { Cartesian Position and Velocity << from
Omnistar HP };
dp      { Dilution of Precision (DOP) Parameters
<< from Omnistar HP };
ss      { Satellite navigation status << from
Omnistar HP };
hp      { data from Omnistar HP };
St      { status Omnistar VBS and Omnistar HP }.
```

```
emulb, /dev/ser/b, /msg/nmea/message
```

message:

```
GGA      { Global Positioning System Fix Data };
GSA      { GNSS DOP and Active Satellites << from
Omnistar HP };
GST      { GNSS Pseudorange Error Statistics <<
from Omnistar HP };
GSV      { GNSS Satellites in View };
VTG      { Course Over Ground and Ground Speed <<
from Omnistar HP }.
```

```
emulb, /dev/ser/b, /msg/vbs
```

dmbulb, ...

dmbulb

OmniSTAR 8400HP User Manual

```
dmbulb,/dev/ser/a
dmbulb,/dev/ser/b
```

OmniStar commands

set,...

```
set,/par/omni/init/fctr,mode
```

```
{ Set OmniStar the parameters to the default factory
value. }
```

mode:

```
  y      {}
  on     {}
  yes    {}

  n      {}
  off    {}
  no     {}.
```

```
set,/par/omni/beam/chan,satellite
```

satellite:

```
  easat  { EA-SAT (Europe) };
  asats  { ASAT S.America };
  amsce  { AMSC (N.America) East };
  amscc  { AMSC Central };
  amscw  { AMSC (N.America) West };
  optus  { Optus Austr./N.Z. };
  xsat   { XSAT Africa/Asia };
  apsat  { AP-Sat (Asia) };
  amsat  { AM-Sat (America) };
  afsat  { AF-Sat (Africa) };
  aorw   { AORW };
  aore   { AORE };
  ior    { IOR };
  por    { POR };
  auto   { automatic scan for Fugro };
  chartco { ChartCo };
  user   { user frequency }.
```

OmniSTAR 8400HP User Manual

set,/par/omni/beam/cfnom,**frequency**

frequency:

in Hz { nominal carrier frequency }.

frequency range:

1525000000 Hz - 1559000000 Hz

for example:

1535152500

set,/par/omni/beam/srnom,**symbolRate**

symbolRate:

609 {};

1219 {};

2438 {};

4876 {}.

set,/par/omni/beam/serv/sid,**xxxx**

xxxx:

in Hexadecimal system { will be used only in "user" mode }.

for example:

c685

set,/par/omni/beam/serv/scrv,**xxxx**

{ scrambler vector }

xxxx:

in Hexadecimal system { will be used only in "user" mode }.

for example:

5c08

OmniSTAR 8400HP User Manual

```
set,/par/omni/beam/srch/span,frequency
```

```
{ search range }
```

frequency:

```
5      { 5 kHz };
10     { 10 kHz };
20     { 20 kHz }.
```

```
set,/par/omni/beam/srch/sid,mode
```

```
{ search rule for SID }
```

mode:

```
off    { not use SID };
userdef { use user defined };
fugro  { will be used SID for Fugro };
chartco { will be used SID for ChartCo }.
```

```
set,/par/omni/beam/srch/power,mode
```

```
{ search rule for "auto" mode }
```

mode:

```
low    { will be used beam with "Low" power (only
        for "auto" mode) };
high   { will be used beam with "High" power
        (only for "auto" mode) }.
```

```
set,/par/omni/hpksp/pos,{position}
```

```
{ Known Start Position }
```

position:

```
{lat,lon,height,stdDevLat,stdDevLon,stdDevHeight}
```

where:

```
lat          Latitude [dm];
lon          Longitude [dm];
height       Ellipsoid Height [m];
stdDevLat    Std Dev Latitude [cm];
stdDevLon    Std Dev Longitude [cm];
stdDevHeight Std Dev Height [cm].
```

format:

OmniSTAR 8400HP User Manual

lat	[N/S] DDdMM.MMMMMm
lon	[E/W] DDDdMM.MMMMMm
height	xxxx.xxx
stdDevLat	xx
stdDevLon	xx
stdDevHeight	xx

example:

```
set,omni/hpksp/pos,{S31d56.6766m,E115d50.5090m,10.24,10,10,20}
```

```
set,/par/omni/hpksp/clear,mode
```

mode:

```
n      {};  
y      {}.
```

```
set,/par/omni/hpstatic,mode
```

```
{ HP Static Initialization }
```

mode:

```
off    {};  
on     {}.
```

```
set,/par/omni/vbssd,mode
```

```
{ VBS Seeding }
```

mode:

```
off    {};  
on     {}.
```

```
set,/par/omni/vbsd/d/mode,param
```

```
{ VBS Dynamic Seeding }
```

param:

```
off    {};  
on     {}.
```

```
set,/par/omni/vbsd/d/time,sec
```

OmniSTAR 8400HP User Manual

```
{ VBS Dynamic Seeding Timer }  
sec: time { second }.  
{ min. value - 1 sec }
```

```
set,/par/omni/debug/john,mode
```

mode:

```
off    {};  
on     {}.
```

```
set,/par/omni/debug/emode,mode
```

mode:

```
hp     { HP Engine Mode };  
xp     { XP Engine Mode }.
```

```
set,/par/omni/smooth,mode
```

mode:

```
off    {};  
on     {}.
```

```
// clear NVRAM
```

```
set,/par/omni/clear,mode
```

mode:

```
n      {};  
y      {}.
```

```
// clear nvr
```

```
set,/par/omni/clear/nvr,mode
```

mode:

```
n      {};  
y      {}.
```

```
// clear HP subscription
```

```
set,/par/omni/clear/hpsub,mode
```

mode:

```
n      {};  
y      {}.
```

```
// clear VBS subscription
```

```
set,/par/omni/clear/vbssub,mode
```

mode:

```
n      {};  
y      {}.
```

print, ...

```
print,/par/omni:on
```

```
print,/par/omni/beam:on
```

```
print,/par/omni/beam/param
```

param:

```
chan    { satellite name };  
cfnom   { nominal carrier frequency };  
srnom   { nominal symbol rate }.
```

```
print,/par/omni/beam/serv:on
```

```
print,/par/omni/beam/serv/param
```

param:

```
sid     { SID };  
scrsv   { scrambler vector }.
```

```
print,/par/omni/beam/srch:on
```

```
print,/par/omni/beam/srch/param
```

param:

```
span    { search range };  
sid     { search rule for SID };
```

OmniSTAR 8400HP User Manual

```
power { search rule for "auto" mode }.
```

```
print,/par/omni/beam/cur:on  
print,/par/omni/beam/cur/param
```

param:

```
chan { satellite name };  
cfnom { nominal carrier frequency };  
cfact { actual carrier frequency };  
srnom { nominal symbol rate };  
sract { actual symbol rate };  
sq { signal quality };  
uw {};  
sid {};  
ber { BER };  
rely {};  
ebno {}.
```

```
print,/par/omni/hpstat:on  
print,/par/omni/hpstat/param
```

param:

```
mapmsg { mapping msg };  
station { stations };  
vel { velocity };  
time { time };  
pos { position };  
eph { ephemeris };  
meas { measurements };  
link { link };  
wet { wet };  
reg { region };  
expr { expiration };  
update { need update };  
status { status RTK float }.
```

```
print,/par/omni/hpwarn:on  
print,/par/omni/hpwarn/param
```

param:

```
datupd { datums updated };  
ellupd { ellipsoids updated };  
glupd { global beams updated };  
satupd { satellites updated };  
stinit { static init mode }.
```

print,/par/omni/hpsub:on

print,/par/omni/hpsub/**param**

param:

```
fugroid { Fugro ID };
start  { starting time };
exp    { expiration time };
hour   { hour glass };
mode   { mode };
modus  { method of operation };
gdate  { expiration gregorian date: Year-Month-
        Day-hours-minutes-seconds,
        e.g. 2004Y02M27D23h59m47s }.
```

print,/par/omni/hpver:on

print,/par/omni/hpbase:on

print,/par/omni/hpbase/id

print,/par/omni/hpksp:on

print,/par/omni/hpksp/**param**

param:

```
pos    { Known Start Position };
clear  { clear KSP }.
```

print,/par/omni/hpstatic:on

print,/par/omni/vbsstat:on

print,/par/omni/vbsstat/**param**

param:

```
time   { time };
pos    { position };
alm    { almanac };
rsit   { remote sites };
link   { link };
wet    { wet };
reg    { region };
expr   { expiration };
```

OmniSTAR 8400HP User Manual

```
update {}.
```

```
print,/par/omni/vbssub:on
```

```
print,/par/omni/vbssub/param
```

param:

```
fugroid { Fugro ID };
start   { starting time };
exp     { expiration time };
hour    { hour glass };
gdate   { expiration gregorian date: Year-Month-
          Day-hours-minutes-seconds,
          e.g. 2004Y02M27D23h59m47s }.
```

```
print,/par/omni/vbsver:on
```

```
print,/par/omni/vbssd:on
```

```
print,/par/omni/vbsdsd/mode:on
```

```
print,/par/omni/vbsdsd/time:on
```

```
print,/par/omni/debug/john:on
```

```
print,/par/omni/debug/emode:on
```

```
print,/par/omni/smooth:on
```

```
print,/par/omni/clear:on
```

```
print,/par/omni/clear/param
```

param:

```
nvr     { clear nvr };
hpsub   { clear HP subscription };
vbssub  { clear VBS subscription }.
```

OmniSTAR 8400HP User Manual

Default parameters

Bulb parameters

bulb/conf	off
bulb/mode	omni
bulb/dev/ser/a/rate	115200
bulb/dev/ser/a/imode	cmd
bulb/dev/ser/a/echo	/dev/null
bulb/dev/ser/a/eoff	#BULB#
bulb/dev/ser/b/rate	153600
bulb/dev/ser/b/imode	jps
bulb/dev/ser/b/echo	/dev/null
bulb/dev/ser/b/eoff	#BULB#
bulb/spectr/carrfrq	1551489000
bulb/spectr/spanfrq	20000
bulb/spectr/filfrq	100
bulb/spectr/detnum	20

OmniStar parameters

omni/beam/chan	auto
omni/beam/cfnom	1551489000
omni/beam/srnom	2438
omni/beam/serv/sid	c685
omni/beam/serv/scrsv	5c08
omni/beam/srch/span	10
omni/beam/srch/sid	fugro
omni/beam/srch/power	high
omni/hpksp/pos	{N00d0.00000m,E000d0.00000m,0.000,00,00,00}
omni/hpstatic	off
omni/vbssd	off
omni/vbsdsd/mode	off
omni/vbsdsd/time	1
omni/smooth	on
omni/debug/john	off
omni/debug/emode	hp

Appendix C

NMEA 0183 Message Options

The OmniSTAR 8400HP is factory configured with 2 NMEA 0183 sentences GGA and GST. The output rate is fixed at a 1 second interval. As an option faster output rates are available up to 20 times per second. There are more messages possible that are GPS receiver specific and not a NMEA 0183 standard.

Firmware version p1	Message Sentence	Description
*	ALM	GPS Almanac Data
	GGA	GPS Fix Data
	GLL	Geographic Position – Latitude/Longitude
	GRS	GPS Range Residuals
*	GSA	GPS DOP and Active Satellites
*	GST	GPS Pseudorange Noise Statistics
*	GSV	GPS Satellites in View
	RMC	Recommended Minimum Specific GPS Data
*	VTG	Track Made Good and Ground Speed
	ZDA	Time and Date

Table 5: NMEA 0183 messages available for the 8400HP

NMEA 0183 Message Formats

In this section each message is described in more detail.

ALM – GPS Almanac Data

The ALM message identifies the GPS week, SV health and contains the almanac for one satellite. One sentence per satellite, up to a maximum of 32.

```
$GPALM,1,1,03,698,00,6ae6,1d,779f,dfef,a10d68,6469a6,7c1f62,  
5f5839,*43
```

Field Number	Description
1	Total number of ALM sentences for this cycle
2	Sentence sequence number
3	SV PRN number, 01 to 32
4	GPS week number
5	SV health status
6	Eccentricity
7	Almanac reference time
8	Inclination angle
9	Rate of right ascension
10	Root of semi-major axis
11	Argument of perigee
12	Longitude of ascension node
13	Mean anomaly
14	A f0, clock parameter
15	A f1, clock parameter

Table 6: Description of the ALM message.

OmniSTAR 8400HP User Manual

GGA – GPS Fix Data

The GGA message includes time, position and fix related data for the GPS receiver.

\$GPGGA,hhmmss.s,llll.llll,a,yyyyy.yyyy,a,x,xx,x.x,x.x,M,x.x,M,x.x,x
xxx

Field Number	Description
1	UTC of Position
2,3	Latitude, N (North) or S (South). *
4,5	Longitude, E (East) or W (West). *
6	GPS Quality Indicator: 0=No GPS, 1=GPS, 2=DGPS, 5=HP.
7	Number of Satellites in Use.
8	Horizontal Dilution of Precision (HDOP).
9,10	Height above Mean Sea level in Meters, M = Meters.
11,12	Geodial Separation in Meters, M = Meters. **
13	Age of Differential GPS Data. ***
14	Differential Reference Station ID (0000 – 1023)

Table 7: Description of the GGA message.

NOTES:

* The GGA message provides 4 decimal points of precision in non-differential mode, and 5 decimal points of accuracy in differential mode.

** Geodial Separation is the difference between the WGS-84 earth ellipsoid and mean-sea-level (MSL).

*** Time in seconds since the last RTCM SC-104 message type 1 or type 9 update.

OmniSTAR 8400HP User Manual

GLL – Geographic Position – Latitude/Longitude

The GLL message contains the latitude and longitude of the present position, the time of the position fix and the status.

\$GPGLL,IIII.III,a,yyyyy.yyy,a,hmmss.s,A

Field Number	Description
1,2	Latitude, N (North) or S (South).
3,4	Longitude, E (East) or W (West).
5	UTC of Position.
6	Status: A = Valid, V = Invalid.

Table 8: Description of the GLL message.

GRS – GPS Range Residuals

The GRS sentence is used to support the Receiver Autonomous Integrity Monitoring (RAIM).

\$GPRGS,220320.0,0,-0.8,-0.2,-0.1,-0.2,0.8,0.6,,,,,,*55

Field Number	Description
1	UTC time of GGA position fix
2	Residuals 0: Residuals used to calculate position given in the matching GGA line 1: Residuals recomputed after the GGA position was computed
3 to 14	Range residuals for satellites used in the navigation solution, in meters

Table 9: Description of the GRS message.

NOTE:

* Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

** If running in HP mode this NMEA message is not valid.

OmniSTAR 8400HP User Manual

GSA – GPS DOP and Active Satellites

The GSA message indicates the GPS receivers operating mode and lists the satellites used for navigation and the DOP values of the position solution.

\$GPGSA,a,x,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,x.x,x.x,x.x

Field Number	Description
1	Mode: M = Manual, A = Automatic.
2	Current Mode 1 = Fix not available, 2 = 2D fix, 3 = 3D fix.
3 to 14	PRN numbers of the satellites used in the position solution. *
15	Position Dilution of Precision (PDOP).
16	Horizontal Dilution of Precision (HDOP).
17	Vertical Dilution of Precision (VDOP)

Table 10: Description of the GSA message.

NOTE:

* When less than 12 satellites are used, the unused fields are null.

OmniSTAR 8400HP User Manual

GST – GPS Pseudorange Noise Statistics

The GST sentence is used to support Receiver Autonomous Integrity Monitoring (RAIM).

\$GPGST,220320.0,1.3,0.8,0.5,166.1,0.8,0.5,1.6,*4F

Field Number	Description
1	UTC time of GGA fix
2	RMS value of the standard deviation of the range inputs to the navigation process (range inputs include pseudo ranges and DGPS corrections)
3	Standard deviation of semi-major axis of error ellipse, in meters
4	Standard deviation of semi-minor axis of error ellipse, in meters
5	Orientation of semi-major axis of error ellipse, in degrees from true north
6	Standard deviation of latitude error, in meters
7	Standard deviation of longitude error, in meters
8	Standard deviation of altitude error, in meters

Table 11: Description of the GST message.

NOTE:

* Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

OmniSTAR 8400HP User Manual

GSV – GPS Satellites in View

The GSV sentence identifies the number of satellites in view, the PRN numbers, elevation, azimuth and SNR values.

```
$GPGSV,4,1,13,02,02,213,,03,-  
3,000,,11,00,121,,14,13,172,05*67
```

Field Number	Description
1	Total number of sentences of this type in this cycle
2	Sentence number
3	Total number of satellites visible
4	SV PRN number
5	Elevation in degrees, 90 ½ maximum
6	Azimuth, degrees from true north, 000 ½ to 359 ½
7	SNR, 00-99 dB (null when not tracking)
8-11	Information about second SV, same format as fields 4-7
12-15	Information about third SV, same format as fields 4-7
16-19	Information about fourth SV, same format as fields 4-7

Table 12: Description of the GSV message.

NOTE:

* Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

OmniSTAR 8400HP User Manual

RMC – Recommended Minimum Specific GPS Data

The RMC sentence identifies the UTC time, status, latitude, longitude, speed over ground (SOG), date and magnetic variation of the position fix.

```
$GPRMC,184804.00,A,3723.476543,N12202.239745,W,000.0,0.0,051196,15.6,E*7C
```

Field Number	Description
1	Time: UTC time of the position fix in hhmmss.ss format
2	Status A: Valid V: Navigation Receiver Warning (V is output whenever the receiver suspects something is wrong)
3	Latitude coordinate
4	Latitude direction: N = North, S = South
5	Longitude coordinate
6	Longitude direction: W = West, E = East
7	Speed Over Ground (SOG) in knots (0-3 decimal places)
8	Track Made Good, True, in degrees
9	Date in dd/mm/yy format
10	Magnetic Variation in degrees
11	Direction of magnetic variation E: Easterly variation from True course (subtracts from True course) W: Westerly variation from True course (adds to True course)
12	Mode Indication A: Autonomous D: Differential N: Data not valid

Table 13: Description of the RMC message.

OmniSTAR 8400HP User Manual

VTG – Course Over Ground and Ground Speed

The VTG sentence identifies the actual track made good and speed over ground.

```
$GPVTG,0,T,,,0.00,N,0.00,K*33
```

Field Number	Description
1	Track made good
2	Fixed text 'T' shows that track made good is relative to true north
3	Not used
4	Not used
5	Speed over ground in knots (0-3 decimal places)
6	Fixed text 'N' shows that speed over ground is in knots
7	Speed over ground in kilometres/hour (0-3 decimal places)
8	Fixed text 'K' shows that speed over ground is in kilometres/hour

Table 14: Description of the VTG message.

NOTE:

* Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

ZDA – Time and Date

The ZDA message contains UTC, the day, the month and the year of the local time zone.

\$GPZDA,hhmmss.s,xx,xx,xxxx,xx,xx

Field Number	Description
1	UTC.
2	Day (0 – 31).
3	Month (0 – 12).
4	Year.
5	Local Zone Description Hours (\pm 13 Hours). *
6	Local Zone Description Minutes.

Table 15: Description of the ZDA message.

NOTES:

* Local zone description is the number of whole hours added to local time to obtain UTC. The zone description is always negative for eastern longitudes. Fields 5 and 6 are Null fields in the "Trimble BD132". A GPS receiver cannot independently identify the local time zone offsets.

* Because the contents of this NMEA message do not change significantly during a 1-second interval, the receiver outputs this message at a maximum rate of 1 Hz.

Appendix D

Acronyms used in this manual

1PPS	One Pulse Per Second
2D	Two Dimensional
3D	Three Dimensional
ASCII	American Standard Code for Information Interchange
BPS	Bits per Second
CEMF	Counter Electro-magnetic Force
DGPS	Differential Global Positioning System
GGA	Global Positioning System fixed data (NMEA standard)
GLL	Geographic position (NMEA standard)
GPS	Global Positioning System
GSA	Global Positioning System, dilution of position, active satellite (NMEA standard)
GSV	GPS satellites in view (NMEA standard)
HP	High Performance
LED	Light Emitting Diode
LNA	Low Noise Amplifier
NCC	Network Control Centre
NMEA	National Marine Electronics Association (Standard for interfacing marine electronic devices)
RF	Radio Frequency
RTCM	Radio Technical Commission Maritime
VTG	'Track mode good' and 'ground speed' (NMEA standard)
ZDA	Time and date (NMEA standard)

Appendix E

List of communication satellites

The following table presents a list of L-band communication satellites, which will enable you to use your 8400HP over the entire world (depending on your subscription type you might only be entitled to a restricted area).

Table 16: World-wide satellite frequencies and baud rates

Satellite Channel	Frequency (MHz)	Baud Rate	Latitude	Longitude
EA-SAT	1535.1525	1200	0° 0' 0.00"	25° 0' 0.00"
AF-SAT	1535.0800	1200	0° 0' 0.00"	25° 0' 0.00"
AP-SAT	1535.1375	1200	0° 0' 0.00"	109°30' 0.00"
AM-SAT	1535.1375	1200	0° 0' 0.00"	-98° 0' 0.00"
OPTUS	1558.5100	1200	-20° 0' 0.00"	145° 0' 0.00"
MSV-West	1536.7820	1200	45° 0' 0.00"	-120° 0' 0.00"
MSV-Central	1534.7410	1200	45° 0' 0.00"	-95° 0' 0.00"
MSV-East	1530.3590	1200	45° 0' 0.00"	-80° 0' 0.00"

Figure 32: Reference stations and coverage area for EA-SAT and AF-SAT.



Figure 33: Reference Stations and coverage area for AM-SAT and AP-SAT.



OmniSTAR 8400HP User Manual

Figure 34: Reference stations and coverage area for OPTUS and MSV-ECW.



APPENDIX F

List of reference stations

The following tables present the current list of reference stations, which are broadcast over the different satellites. Check www.surveyplanner.com for the latest updates of these lists.

Table 17: Reference stations on EA-SAT

Nr	Station	ID	VBS	HP
1	Abu Dhabi, UAE	016	YES	YES
2	Kuwait	290	YES	YES
3	Bahrain	260	YES	NO
4	Aberdeen, Scotland	571	YES	YES
5	Alexandria, Egypt	310	YES	NO
7	Baku, Azerbaijan	400	YES	NO
8	Bodo, Norway	122	YES	NO
9	Crete, Greece	340	YES	NO
10	Faro, Portugal	371	YES	YES
11	Istanbul, Turkey	410	YES	NO
12	Leidschendam, The Netherlands	521	YES	YES
13	Malta	351	YES	NO
14	Ny Alesund, Spitsbergen	101	YES	NO
15	Orlandet, Norway	630	YES	YES
16	Rogaland, Norway	580	YES	YES
17	Shannon, Ireland	530	YES	NO
18	Torshavn, Faroes	620	YES	NO
19	Toulouse, France	431	YES	NO
20	Tromso, Norway	690	YES	NO
21	Vardo, Norway	114	YES	NO
22	Visby, Sweden	229	YES	NO
23	Vienna, Austria	480	YES	NO
24	Kharkiv, Ukraine	500	YES	NO

OmniSTAR 8400HP User Manual

Table 18: Reference stations on AF-SAT

Nr	Station	ID	VBS	HP
1	Abidjan, Ivory Coast	050	YES	NO
2	Blantyre, Malawi	155	YES	NO
3	Cape Town, South Africa	335	YES	NO
4	Dakar, Senegal	144	YES	NO
5	Douala, Cameroon	043	YES	YES
6	Durban, South Africa	305	YES	NO
7	Faro, Portugal	371	YES	NO
8	Lagos, Nigeria	060	YES	NO
9	Las Palmas, Canaries	280	YES	NO
10	Luanda, Angola	095	YES	YES
11	Nairobi, Kenya	015	YES	NO
13	Pointe-Noire, Congo	045	YES	YES
14	Port Elizabeth, South Africa	337	YES	NO
15	Rogaland, Norway	580	YES	YES
16	Sao Tome, Sao Tome	011	YES	YES
17	Walvis Bay, Namibia	235	YES	NO

Table 19: Reference stations on AP-Sat

Nr	Station	ID	VBS	HP
1	Auckland, NZ	022	YES	NO
2	Karratha, Australia	215	YES	NO
3	Darwin, Australia	125	YES	NO
4	Broome, Australia	185	YES	NO
9	Asahikawa, Japan	261	YES	NO
10	Singapore	010	YES	YES
11	Miri, Malaysia	042	YES	YES
12	Vung Tua, Vietnam	012	YES	YES
13	Hong Kong	220	YES	NO
14	Seoul, S. Korea	370	YES	NO
15	Kota Kinabalu, Malaysia	061	YES	NO

OmniSTAR 8400HP User Manual

16	Bali, Indonesia	096	YES	YES
17	Mumbai-Arvi, India	191	YES	YES
19	Subic Bay, Phillipines	151	YES	NO
20	Kuwait	290	YES	NO
21	Abu Dhabi, UAE	016	YES	NO
23	Kuantan, Malaysia	041	YES	NO
25	Bangkok, Thailand	141	YES	YES
26	Chennai, India	131	YES	NO
27	Bathurst, Australia	336	YES	NO
28	Kalgoorlie, Australia	315	YES	NO
31	Melbourne, Australia	385	YES	NO
32	Okinawa, Japan	261	YES	NO
33	Platong, Thailand	018	YES	NO
34	Sakhalin, Russia	510	YES	NO
35	Bahrain, Bahrain	260	YES	NO

Table 20: Reference stations on AM-Sat

Nr	Station	ID	VBS	HP
1	Houston, Texas	100	YES	YES
2	Cocoa Beach, Florida	120	YES	YES
3	Long Island, New York	333	YES	YES
4	Carmen, Mexico	110	YES	YES
5	Punta Arenas, Chile	210	YES	NO
6	Guayaquil, Ecuador	202	YES	NO
7	Rio de Janeiro, Brazil	225	YES	YES
8	St. Johns, Newfoundland	470	YES	YES
9	Dartmouth, Nova Scotia	440	YES	NO
10	Recife, Brazil	075	YES	NO
11	Port Of Spain, Trinidad	111	YES	YES
12	Caracas, Venezuela	112	YES	YES
13	Belem, Brazil	017	YES	NO
14	Caymen, Grand Cayman	192	YES	YES

OmniSTAR 8400HP User Manual

15	Honolulu, USA	210	YES	NO
16	Curtiba, Brazil	257	YES	YES
17	Pensacola, USA	301	YES	YES
18	Vitoria, Brazil	205	YES	YES
19	Mercedes, USA	263	YES	YES
20	Buenos Aires, Argentina	345	YES	NO

APPENDIX G

Receiver Service Procedure

If an OmniSTAR receiver unit fails to perform, please contact the OmniSTAR office within your region, after following the procedural checks. We wish to hear about frequently experienced problems and your assistance will help by copying the form on the next page, filling in the details requested and faxing or mailing the form to the OmniSTAR office.

The most common problems are interfacing, and usually occur at installation time. If you have an interfacing connection not covered in this manual we would like to assist you and produce another technical bulletin that may assist other users in the future.

If a problem appears that you think may be caused by a system performance problem, please contact the OmniSTAR office in your region for any system aberrations that may have been experienced.

We are sensitive to our customers' needs and we want to assure specified system performance at all times. There could, however, be situations where conditions are below par, such as fringe area operations, radio communication disturbance etc., and, as the OmniSTAR receiver monitors the system performance continuously, these conditions would be noted.

APPENDIX H

OmniSTAR Receiver Problem Report Form

Please copy this form and report problem with as much detail as possible.

Problem with: Signal Y/N OmniSTAR Y/N		Date:
Manual Y/N Receiver Y/N		
Description of problem:		
Person Reporting:		Contact Phone #:
Model #:		Serial #:
Customer Name:		Customer Address:
Customer Phone #:		
Date purchased: / /		Dealer:
GPS Receiver used:		Serial #:
Area of operations:		
Symptoms from display (if any):		

